

# Example: An RGB Stage Light

Every lighting equipment manufacturer sets up their equipment in a slightly different way. For this reason, it's essential to consult the equipment manual during programming to determine the 'DMX Channel Map'.

A very basic example would be an RGB stage light. It could be designed to run in several different modes:

- 3 channels. Three consecutive DMX channels drive red, green and blue. Super simple to operate.
- 4 channels. As above, but a fourth channel controls 'master intensity.' If this fourth channel is turned off, the fixture will appear unresponsive.
- 5+ channels. As above, but some fixtures include built-in effects such as sound activation, color cycling, strobing in various colors and at different speeds. The map for one of these systems might look like this:

To make this particular fixture work properly, DMX channel 4 must always be set to 100%.

**Without channel 4 being turned on, the fixture will appear unresponsive.** If written on a musical staff, this would correspond to a whole note which lasts for many measures:

CH 1  
CH 2  
CH 3

RED  
GREEN  
BLUE

4

0

0

0%--100% DIMMER

5 WITH CH 6)

1-2-3-4 1-2-3-4

IN

Revision #1	150—199	PULSE
Created Wed, Oct 30, 2019 2:30 PM by ESINC	200—249	CYCLE
Updated Wed, Oct 30, 2019 2:42 PM by ESINC	250—255	MUSIC ACTIVATED